

Replacing your external In-Line Filter with push fittings;

1/ Find the isolation valve which will be located somewhere on the water supply line to the filter. Turn it off and to depressurise the system draw a glass of water from the water outlet at the fridge. You will only get a few drops and this will confirm the water supply is turned off.



You can use your fingers or a firm edged object to hold down collet—this will allow the hose to easily slide out.

Rinse your filter into a container or bucket to remove loose carbon and to activate the filter correctly.



2/ Have a bucket and towel ready as there will be a small spillage of water during this process. To remove the old filter, using your thumb nail or the edge of a teaspoon, depress the floating white plastic collet which holds the plastic tubing. Keeping the collet depressed, simply pull the tube out.

3/ Take the new filter, making sure the flow direction is correct and connect the inlet side only by inserting the tube and pushing it in approx 8 – 10mm. You will feel it hit home.

4/ **IMPORTANT** - Placing the filter in the bucket, turn on the water supply and allow about 3 litres of water to flow through the filter and into the bucket. This will remove any loose carbon fines. Once done, turn off the water supply and connect the remaining tube to the outlet side of the filter. Turn on the water supply and run approx 2 litres through the system.

5/ Complete the Replacement Due sticker and place in a visible area inside the fridge door.

6/ Any problems please call our 1300 724249 hotline.